





AS183 Discovery 4 & Range Rover Sport
3.0 litre twin turbo SDV6
uprated intercooler fitting notes

- Please note although intercooler installation is straightforward, the front of the car will need to be dismantled to achieve access. Allow sufficient time for the work to be completed, we suggest minimum one day
- Also note, it will be necessary to empty and refill the AC gas to allow removal of the condenser
- The AC condenser / radiator plastic cowl must be notched to add clearance
- AC condenser needs to be spaced out using supplied rubber mounts
- Fuel cooler pipes need to be extended using rubber fuel hose
- As the radiator pack relocates forwards slightly, the aluminium frame will need a small notch cutting for clearance where the condenser mounts
- Bend the horn bracket forwards slightly
- See images below

























